


Coil Casing Section

- ☐ 1. Drift eliminators
- ☐ 2. Spray branches
- ☐ 3. Spray branch grommets
- ☐ 4. Spray nozzles & nozzles grommets
- ☐ 5. Spray header
- ☐ 6. Coil(s)
- ☐ 7. Pump piping
- ☐ 8. Sleeve & clamps

Pan Fan Section

- ☐ 9. Spray pump
 - ☐ with volute
 - ☐ without volute
 - ☐ seal kit
- ☐ 10. Strainer
- ☐ 11. Make-up valve & arm
- ☐ 12. Float ball
- ☐ 13. Heater
- ☐ 14. Heater thermostat
- ☐ 15. Low level cut out switch
- ☒ 16. Centrifugal fan assembly (see detailed view)
- ☐ 17. Motor base with adjuster
- ☐ 18. Access door & gasket
- ☐ 19. Fan guard
- ☐ 20. Fan housing - upper
- ☐ 21. Fan housing - lower
- ☐ 22. Fan inlet ring



Spray pump with volute



Spray pump without volute




Seal kit




13



14



15



Centrifugal fan assembly

- ☐ A. Centrifugal fan wheel
- ☐ B. Fan shaft
- ☐ C. Bearing drive end with locking collar
- ☐ D. Bearing non-drive end with locking collar
- ☐ E. Bearing support
- ☐ F. Fan motor
- ☒ G. Drive set
 - ☐ Motor sheave & bushing
 - ☐ Fan sheave & bushing
 - ☐ Belt set



G

C

B

D

E

F

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

AL

AM

AN

AO

AP

AQ

AR

AS

AT

AU

AV

AW

AX

AY

AZ

BA

BB

BC

BD

BE

BF

BG

BH

BI

BJ

BK

BL

BM

BN

BO

BP

BQ

BR

BS

BT

BU

BV

BW

BX

BY

BZ

CA

CB

CC

CD

CE

CF

CG

CH

CI

CJ

CK

CL

CM

CN

CO

CP

CQ

CR

CS

CT

CU

CV

CW

CX

CY

CZ

DA

DB

DC

DD

DE

DF

DG

DH

DI

DJ

DK

DL

DM

DN

DO

DP

DQ

DR

DS

DT

DU

DV

DW

DX

DY

DZ

EA

EB

EC

ED

EE

EF

EG

EH

EI

EJ

EK

EL

EM

EN

EO

EP

EQ

ER

ES

ET

EU

EV

EW

EX

EY

EZ

FA

FB

FC

FD

FE

FF

FG

FH

FI

FJ

FK

FL

FM

FN

FO

FP

FQ

FR

FS

FT

FU

FV

FW

FX

FY

FZ

GA

GB

GC

GD

GE

GF

GG

GH

GI

GJ

GK

GL

GM

GN

GO

GP

GQ

GR

GS

GT

GU

GV

GW

GX

GY

GZ

HA

HB

HC

HD

HE

HF

HG

HH

HI

HJ

HK

HL

HM

HN

HO

HP

HQ

HR

HS

HT

HU

HV

HW

HX

HY

HZ

IA

IB

IC

ID

IE

IF

IG

IH

II

IJ

IK

IL

IM

IN

IO

IP

IQ

IR

IS

IT

IU

IV

IW

IX

IY

IZ

JA

JB

JC

JD

JE

JF

JG

JH

JI

JJ

JK